


NGL[®]

Nasser Global Links
ناصر جلوبل لينكس


NASSER'S
125 YEARS
OF INTERNATIONAL TRADE
1888-2013




Bicycle Maintenance Manual

SINCERE SERVICE | SECURED SOURCE | SPIRITED SUPPLIER


Frame




Fork




Tire




Spoke







Valve Types




Hub




Components


	Tire Lever
	Hacksaw Blade
	Cutting Tool
	Patching Glue




Remove tube




Hold underwater to locate hole




Cut patch from old tube



Scratch patch area with hacksaw blade or sandpaper



Add patching glue to tube and patch




Press patch down hard on tube



Tube Repair

www.nasserglobal.com

















	10mm spanner
	15mm spanner
	26mm spanner
	36mm spanner
	Lockring spanner
	Hammer
	Cotter Anvil


A		Frame
B		BB Spindle
C		BB Bearings (2)
D		Adjustable Cup
E		Lockring
F		Fixed Cup
G		Left Crank Arm



H		Right Crank Arm and Chainring
I		Cotter Pins (2)
J		Cotter Pin Washers (2)
K		Cotter Pin Nuts (2)
L		Left Pedal
M		Right Pedal



Bottom Bracket

A		Frame
B		Fork
C		Headset Bearing (2)
D		Upper Headset Race
E		Lamp Bracket
F		Headset Spacer
G		Lock Nut
H		Expander Bolt
I		Washer
J		Handlebars
K		Handlebar Grips (2)
L		Stem
M		Stem Bolt
N		Expander Wedge



	13mm spanner
	30mm spanner









NGL[®]




Headset

www.nasserglobal.com



A		Master Link
B		Master Link Side Plate
C		Retaining Clip
D		Chain







NGL[®]










Chain


www.nasserglobal.com




	15mm spanner
	17mm spanner
	15mm cone spanner




A		Axle
B		Hub Shell
C		Bearing (2)
D		Cone
E		Locknut
F		Axle Washers (2)
G		Axle Nuts (2)

H		Fork
---	--	------



Front Hub




	10mm Spanner
	15mm Spanner
	17mm Spanner
	Screwdriver
	15mm cone spanner


A		Axle Nut (2)
B		Axle Washers (2)
C		Snap Ring
D		Cog
E		Right Dust Cover
F		Lock Nuts (2)
G		Bearing Shield
H		Cone
I		Small Bearing

J		Hub Driver
K		Large Bearings (2)
L		Hub Shell
M		Axle
N		Clutch Cone
O		Clutch Washer
P		Clutch Spring
Q		Spring Holder
R		Brake Shoes


S		Brake Cone
T		Left Dust Cover
U		Brake Arm
V		Washer
W		Bolt
X		Brake Arm Clip
Y		Nut



KT Rear Hub





-or-



2


# of crossings	Hub holes
4x	10
3x	8
2x	6
1x	4





Wheel Lacing




Truing



Rounding




Tighten




Loosen


Dishing



Rim Off Center



Correctly Dished



Rim Off Center



Wheel Alignment



Nasser Global Links

Bringing you the Globe...



1 Palekar Chambers, 12, First Marine Street, Mumbai 400 002. INDIA.
M: +91 9820068323 T: +91 22 22015044 E: info@nasserglobal.com W: www.nasserglobal.com

SINCERE SERVICE | SECURED SOURCE | SPIRITED SUPPLIER